

No.	オールインワン 機器配線付	配線なし	ボックスのみ	備考	スイッチ メーカー	スイッチ1	スイッチ2	スイッチ3	スイッチ4	スイッチ5
1	AIO-A104	NBC-104	D4B-140B	回り止めなし	オムロン	C1S-702R	-	-	-	-
2	AIO-A10H	NBC-10H	D4B-130B		オムロン	C1S-703G	-	-	-	-
3	AIO-A115	NBC-115	D8B-130B		オムロン	C1S-710R	-	-	-	-
4	AIO-A119	NBC-119	D8B-130B		オムロン	C1S-712G	-	-	-	-
5	AIO-A11C	NBC-11C	D8B-130B		オムロン	C1S-716G	-	-	-	-
6	AIO-A11M	NBC-11M	D8B-130B		オムロン	C1S-717G	-	-	-	-
7	AIO-A208	NBC-208	D4B-231B		オムロン	C1S-703G	C1S-703R	-	-	-
8	AIO-A212	NBC-212	D8B-230B		オムロン	C1S-712G	C1S-710R	-	-	-
9	AIO-A215	NBC-215	D8B-233B		オムロン	C1S-712G	C1S-712R	-	-	-
10	AIO-A21D	NBC-21D	D8B-233B		オムロン	C1S-717G	C1S-717R	-	-	-
11	AIO-A30D	NBC-30D	D4B-331B		オムロン	C1S-703G	C1S-703R	C1S-703Y	-	-
12	AIO-A312	NBC-312	D8B-330B		オムロン	C1S-712G	C1S-712R	C1S-710R	-	-
13	AIO-A315	NBC-315	D8B-330B		オムロン	C1S-713G	C1S-713R	C1S-710R	-	-
14	AIO-A31B	NBC-31B	D8B-333B		オムロン	C1S-712G	C1S-712R	C1S-712Y	-	-
15	AIO-A31H	NBC-31H	D8B-333B		オムロン	C1S-717G	C1S-717R	C1S-717Y	-	-
16	AIO-C108	NDC-108	D4B-130B		オムロン	C1S-607G	-	-	-	-
17	AIO-C10J	NDC-10J	D4B-130B		オムロン	C1S-704G	-	-	-	-
18	AIO-C116	NDC-116	D8B-130B		オムロン	C1S-711R	-	-	-	-
19	AIO-C11A	NDC-11A	D8B-130B		オムロン	C1S-713G	-	-	-	-
20	AIO-C11N	NDC-11N	D8B-130B		オムロン	C1S-718G	-	-	-	-
21	AIO-C20A	NDC-20A	D4B-231B		オムロン	C1S-704G	C1S-704R	-	-	-
22	AIO-C213	NDC-213	D8B-230B		オムロン	C1S-713G	C1S-711R	-	-	-
23	AIO-C217	NDC-217	D8B-233B		オムロン	C1S-713G	C1S-713R	-	-	-
24	AIO-C21E	NDC-21E	D8B-233B		オムロン	C1S-718G	C1S-718R	-	-	-
25	AIO-C30E	NDC-30E	D4B-331B		オムロン	C1S-704G	C1S-704R	C1S-704Y	-	-
26	AIO-C314	NDC-314	D8B-330B		オムロン	C1S-712G	C1S-712R	C1S-711R	-	-
27	AIO-C316	NDC-316	D8B-330B		オムロン	C1S-713G	C1S-713R	C1S-711R	-	-
28	AIO-C31C	NDC-31C	D8B-333B		オムロン	C1S-713G	C1S-713R	C1S-713Y	-	-
29	AIO-C31J	NDC-31J	D8B-333B		オムロン	C1S-718G	C1S-718R	C1S-718Y	-	-
30	AIO-E10A	NFC-10A	D4B-140B	回り止めなし	IDEC	C1S-670R	-	-	-	-
31	AIO-E10B	NFC-10B	D4B-131B		IDEC	C1S-686G	-	-	-	-
32	AIO-E10F	NFC-10F	D4B-130B		IDEC	C1S-650G	-	-	-	-

No.	オールインワン 機器配線付	配線なし	ボックスのみ	備考	スイッチ メーカー	スイッチ1	スイッチ2	スイッチ3	スイッチ4	スイッチ5
33	AIO-G104	NHC-104	D4B-130B		IDEC	C1S-627G	-	-	-	-
34	AIO-G10C	NHC-10C	D4B-131B		IDEC	C1S-687G	-	-	-	-
35	AIO-G30E	NHC-30E	D4B-332B		IDEC	C1S-687G	C1S-687R	C1S-687Y	-	-
36	AIO-M101	NBC-101	D4B-140B	回り止めなし	オムロン	C1S-601R	-	-	-	-
37	AIO-M102	NDC-102	D4B-140B	回り止めなし	オムロン	C1S-603R	-	-	-	-
38	AIO-M103	NDC-103	D4B-140B	回り止めなし	オムロン	C1S-604R	-	-	-	-
39	AIO-M104	NBC-107	D4B-130B		オムロン	C1S-605G	-	-	-	-
40	AIO-M106	NBC-10B	D4B-130B		オムロン	C1S-609G	-	-	-	-
41	AIO-M107	NFC-107	D4B-140B	回り止めなし	IDEC	C1S-683R	-	-	-	-
42	AIO-M108	NHC-108	D4B-140B	回り止めなし	IDEC	C1S-685R	-	-	-	-
43	AIO-M109	NHC-109	D4B-140B	回り止めなし	IDEC	C1S-684R	-	-	-	-
44	AIO-M111	NFC-101	D4B-130B		IDEC	C1S-624G	-	-	-	-
45	AIO-M112	NQC-102	CDB-110Q		EAO	C1S-261G	-	-	-	-
46	AIO-M113	NUC-103	CDB-112Q		シンデン	C1S-901R	-	-	-	-
47	AIO-M114	NUC-104	CDB-112Q		シンデン	C1S-901G	-	-	-	-
48	AIO-M201	NBC-201	D4B-240B	回り止めなし	オムロン	C1S-605G	C1S-601R	-	-	-
49	AIO-M202	NFC-202	D4B-240B	回り止めなし	IDEC	C1S-624G	C1S-683R	-	-	-
50	AIO-M203	NQC-203	CDB-211Q		EAO	C1S-261G	C1S-261R	-	-	-
51	AIO-M204	NBC-204	D4B-231B		オムロン	C1S-605G	C1S-605R	-	-	-
52	AIO-M205	NFC-205	D4B-231B		IDEC	C1S-624G	C1S-624R	-	-	-
53	AIO-M206	NDC-206	D4B-240B	回り止めなし	オムロン	C1S-607G	C1S-603R	-	-	-
54	AIO-M207	NHC-206	D4B-240B	回り止めなし	IDEC	C1S-627G	C1S-685R	-	-	-
55	AIO-M208	NSC-208	CDB-211Q		EAO	C1S-262G	C1S-262R	-	-	-
56	AIO-M209	NDC-209	D4B-231B		オムロン	C1S-607G	C1S-607R	-	-	-
57	AIO-M210	NHC-201	D4B-231B		IDEC	C1S-627G	C1S-627R	-	-	-
58	AIO-M211	NUC-201	CDB-212Q		シンデン	C1S-901G	C1S-901R	-	-	-
59	AIO-M212	NFC-20A	D4B-232B		IDEC	C1S-686G	C1S-686R	-	-	-
60	AIO-M213	NHC-203	D4B-232B		IDEC	C1S-687G	C1S-687R	-	-	-
61	AIO-M301	NBC-301	D4B-340B	回り止めなし	オムロン	C1S-605G	C1S-605R	C1S-601R	-	-
62	AIO-M302	NFC-302	D4B-340B	回り止めなし	IDEC	C1S-624G	C1S-624R	C1S-683R	-	-
63	AIO-M303	NDC-303	D4B-340B	回り止めなし	オムロン	C1S-605G	C1S-605R	C1S-603R	-	-
64	AIO-M304	NHC-304	D4B-340B	回り止めなし	IDEC	C1S-624G	C1S-624R	C1S-685R	-	-

No.	オールインワン 機器配線付	配線なし	ボックスのみ	備考	スイッチ メーカー	スイッチ1	スイッチ2	スイッチ3	スイッチ4	スイッチ5
65	AIO-M305	NBC-307	D4B-331B		オムロン	C1S-605G	C1S-605R	C1S-605Y	-	-
66	AIO-M306	NFC-306	D4B-331B		IDEC	C1S-624G	C1S-624R	C1S-624Y	-	-
67	AIO-M307	NQC-307	CDB-311Q		EAO	C1S-261G	C1S-261R	C1S-261Y	-	-
68	AIO-M308	NBC-308	D4B-340B	回り止めなし	オムロン	C1S-607G	C1S-607R	C1S-601R	-	-
69	AIO-M309	NFC-309	D4B-340B	回り止めなし	IDEC	C1S-627G	C1S-627R	C1S-683R	-	-
70	AIO-M310	NDC-309	D4B-340B	回り止めなし	オムロン	C1S-607G	C1S-607R	C1S-603R	-	-
71	AIO-M311	NHC-301	D4B-340B	回り止めなし	IDEC	C1S-627G	C1S-627R	C1S-685R	-	-
72	AIO-M312	NDC-30A	D4B-331B		オムロン	C1S-607G	C1S-607R	C1S-607Y	-	-
73	AIO-M313	NHC-303	D4B-331B		IDEC	C1S-627G	C1S-627R	C1S-627Y	-	-
74	AIO-M315	NUC-305	CDB-312Q		シンデン	C1S-901G	C1S-901R	C1S-901Y	-	-
75	AIO-M316	NFC-30D	D4B-332B		IDEC	C1S-686G	C1S-686R	C1S-686Y	-	-
76	AIO-P103	NQC-103	CDB-110Q		EAO	C1S-261R	-	-	-	-
77	AIO-P105	NQC-105	CDB-110Q		EAO	C1S-263G	-	-	-	-
78	AIO-R101	NSC-101	CDB-110Q		EAO	C1S-262G	-	-	-	-
79	AIO-R104	NSC-104	CDB-110Q		EAO	C1S-262R	-	-	-	-
80	AIO-R308	NSC-308	CDB-311Q		EAO	C1S-262G	C1S-262R	C1S-262Y	-	-
81	APC-S001	NBC-107	D4B-130B		オムロン	C1S-605G	-	-	-	-
82	APC-S002	NBC-107	D4B-130B		オムロン	C1S-605G	-	-	-	-
83	APC-S003	-	D4B-130B		オムロン	C1S-605R	-	-	-	-
84	APC-S004	-	D4B-130B		オムロン	C1S-605R	-	-	-	-
85	APC-S005	-	D4B-130B		オムロン	C1S-605R	-	-	-	-
86	APC-S006	-	D5B-370B		オムロン/EAO	C1S-261G	C1S-601R	C1S-261G	-	-
87	APC-S007	-	D5B-270B		EAO	C1S-261G	C1S-261G	-	-	-
88	APC-S008	-	D5B-380B		オムロン/EAO	C1S-261G	C1S-601R	C1S-261G	-	-
89	APC-S009	-	D5B-280B		EAO	C1S-261G	C1S-261G	-	-	-
90	APC-S010	-	D4B-370B		オムロン/EAO	C1S-261G	C1S-601R	C1S-261G	-	-
91	APC-S011	-	D4B-270B		EAO	C1S-261G	C1S-261G	-	-	-
92	APC-S012	-	D4B-380B		オムロン/EAO	C1S-261G	C1S-601R	C1S-261G	-	-
93	APC-S013	-	D4B-280B		EAO	C1S-261G	C1S-261G	-	-	-
94	APC-S014	-	D9B-370N		IDEC	C1S-732G	C1S-731R	C1S-732G	-	-
95	APC-S015	-	D9B-270N		IDEC	C1S-732G	C1S-732G	-	-	-
96	APC-S016	-	D9B-380N		IDEC	C1S-732G	C1S-731R	C1S-732G	-	-

No.	オールインワン 機器配線付	配線なし	ボックスのみ	備考	スイッチ メーカー	スイッチ1	スイッチ2	スイッチ3	スイッチ4	スイッチ5
97	APC-S017	-	D9B-280N		IDEC	C1S-732G	C1S-732G	-	-	-
98	APC-S018	-	D8B-370N		IDEC	C1S-732G	C1S-731R	C1S-732G	-	-
99	APC-S019	-	D8B-270N		IDEC	C1S-732G	C1S-732G	-	-	-
100	APC-S020	-	D8B-380N		IDEC	C1S-732G	C1S-731R	C1S-732G	-	-
101	APC-S021	-	D8B-280N		IDEC	C1S-732G	C1S-732G	-	-	-
102	APC-S022	-	-		IDEC	C1S-722R	-	-	-	-
103	APC-S023	-	-		IDEC	C1S-734G	-	-	-	-
104	APC-S024	-	-		IDEC	C1S-733G	-	-	-	-
105	APC-S025	-	D6B-230N		IDEC	C1S-734G	C1S-722R	-	-	-
106	APC-S026	-	D6B-230N		IDEC	C1S-733G	C1S-722R	-	-	-
107	APC-S027	-	-		シンデン	C1S-903	-	-	-	-
108	APC-S028	-	-		シンデン	C1S-904	-	-	-	-
109	APC-S029	-	-		シンデン	C1S-905	-	-	-	-
110	APC-S030	-	-		シンデン	C1S-903	-	-	-	-
111	APC-S031	-	-		シンデン	C1S-904	-	-	-	-
112	APC-S032	-	-		シンデン	C1S-905	-	-	-	-
113	APC-S033	-	-		IDEC	C1S-685R	-	-	-	-
114	APC-S034	-	-		IDEC	C1S-735R	-	-	-	-
115	APC-S036	-	D4B-130B		オムロン	C1S-612N	-	-	-	-
116	APC-S037	-	DEB-130B		IDEC	C1S-680N	-	-	-	-
117	APC-S038	-	DEB-130B		富士	C1S-642N	-	-	-	-
118	APC-S039	-	D6B-130B		オムロン	C1S-270N	-	-	-	-
119	APC-S040	-	D6B-130B		IDEC	C1S-212N	-	-	-	-
120	APC-S041	-	D6B-130B		富士	C1S-242N	-	-	-	-
121	APC-S042	-	D4B-440B		オムロン	C1S-605G	C1S-605R	C1S-605Y	C1S-601R	-
122	APC-S043	-	D4B-431B		オムロン	C1S-605G	C1S-605G	C1S-605R	C1S-605Y	-
123	APC-S044	-	D8B-430B		オムロン	C1S-712G	C1S-712R	C1S-712Y	C1S-710R	-
124	APC-S045	-	D8B-433B		オムロン	C1S-712G	C1S-712G	C1S-712R	C1S-712Y	-
125	APC-S046	-	-		IDEC	C1S-686G	C1S-683R	-	-	-
126	APC-S047	-	-		IDEC	C1S-686G	C1S-686R	C1S-683R	-	-
127	APC-S048	-	-		IDEC	C1S-686G	C1S-683R	-	-	-
128	APC-S049	-	-		IDEC	C1S-686G	C1S-686R	C1S-683R	-	-

No.	オールインワン 機器配線付	配線なし	ボックスのみ	備考	スイッチ メーカー	スイッチ1	スイッチ2	スイッチ3	スイッチ4	スイッチ5
129	APC-S050	-	-		IDEC	C1S-686G	C1S-683R	-	-	-
130	APC-S051	-	-		IDEC	C1S-686G	C1S-686R	C1S-683R	-	-
131	APC-S052	-	D8B-230B		IDEC	C1S-736G	C1S-722R	-	-	-
132	APC-S053	-	D8B-330B		IDEC	C1S-736G	C1S-736R	C1S-722R	-	-
133	APC-S054	-	D9B-230N		IDEC	C1S-736G	C1S-722R	-	-	-
134	APC-S055	-	D9B-330N		IDEC	C1S-736G	C1S-736R	C1S-722R	-	-
135	APC-S056	-	D4B-370B		富士	C1S-248G	C1S-757R	C1S-248G	-	-
136	APC-S057	-	D4B-380B		富士	C1S-248G	C1S-757R	C1S-248G	-	-
137	APC-S058	-	D5B-370B		富士	C1S-248G	C1S-757R	C1S-248G	-	-
138	APC-S059	-	D5B-380B		富士	C1S-248G	C1S-757R	C1S-248G	-	-
139	APC-S060	-	D8B-370N		富士	C1S-249G	C1S-231R	C1S-249G	-	-
140	APC-S061	-	D8B-380N		富士	C1S-249G	C1S-231R	C1S-249G	-	-
141	APC-S062	-	D9B-370N		富士	C1S-249G	C1S-231R	C1S-249G	-	-
142	APC-S063	-	D9B-380N		富士	C1S-249G	C1S-231R	C1S-249G	-	-
143	APC-S064	APC-S065	D8B-140B		オムロン	C1S-619R	-	-	-	-
144	APC-S066	APC-S067	D8B-140B		富士	C1S-767R	-	-	-	-
145	APC-S068	-	D8B-132B		IDEC	C1S-316R	-	-	-	-
146	APC-S069	-	D8B-132B		富士	C1S-346R	-	-	-	-
147	APC-S070	-	D8B-132B		富士	C1S-347R	-	-	-	-
148	APC-S071	-	-		IDEC	C1S-657R	-	-	-	-
149	APC-S072	-	-		IDEC	C1S-658R	-	-	-	-
150	APC-S074	-	-		IDEC	C1S-657R	-	-	-	-
151	APC-S075	-	-		IDEC	C1S-658R	-	-	-	-
152	NAC-105	NBC-105	D6B-130B		オムロン	C1S-710R	-	-	-	-
153	NAC-109	NBC-109	D6B-130B		オムロン	C1S-712G	-	-	-	-
154	NAC-10C	NBC-10C	D6B-130B		オムロン	C1S-716G	-	-	-	-
155	NAC-111	NBC-111	DEB-140B	回り止めなし	オムロン	C1S-601R	-	-	-	-
156	NAC-114	NBC-114	DEB-140B	回り止めなし	オムロン	C1S-702R	-	-	-	-
157	NAC-117	NBC-117	DEB-130B		オムロン	C1S-605G	-	-	-	-
158	NAC-11B	NBC-11B	DEB-130B		オムロン	C1S-609G	-	-	-	-
159	NAC-11H	NBC-11H	DEB-130B		オムロン	C1S-703G	-	-	-	-
160	NAC-121	NBC-121	D5B-140B	回り止めなし	オムロン	C1S-601R	-	-	-	-

No.	オールインワン 機器配線付	配線なし	ボックスのみ	備考	スイッチ メーカー	スイッチ1	スイッチ2	スイッチ3	スイッチ4	スイッチ5
161	NAC-124	NBC-124	D5B-140B	回り止めなし	オムロン	C1S-702R	-	-	-	-
162	NAC-125	NBC-125	D9B-130N		オムロン	C1S-710R	-	-	-	-
163	NAC-127	NBC-127	D5B-130B		オムロン	C1S-605G	-	-	-	-
164	NAC-129	NBC-129	D9B-130N		オムロン	C1S-712G	-	-	-	-
165	NAC-12B	NBC-12B	D5B-130B		オムロン	C1S-609G	-	-	-	-
166	NAC-12C	NBC-12C	D9B-130N		オムロン	C1S-716G	-	-	-	-
167	NAC-12H	NBC-12H	D5B-130B		オムロン	C1S-703G	-	-	-	-
168	NAC-12L	NBC-12L	D9B-130N		オムロン	C1S-717G	-	-	-	-
169	NAC-151	NBC-151	CTB-110T	回り止めなし	オムロン	C1S-601R	-	-	-	-
170	NAC-153	NBC-153	CTB-110T	回り止めなし	オムロン	C1S-702R	-	-	-	-
171	NAC-155	NBC-155	CUB-110U		オムロン	C1S-710R	-	-	-	-
172	NAC-159	NBC-159	CUB-110U		オムロン	C1S-712G	-	-	-	-
173	NAC-15J	NBC-15J	CUB-110U		オムロン	C1S-716G	-	-	-	-
174	NAC-15L	NBC-15L	CUB-110U		オムロン	C1S-717G	-	-	-	-
175	NAC-167	NBC-167	CTB-110T	回り止めなし	オムロン	C1S-605G	-	-	-	-
176	NAC-16B	NBC-16B	CTB-110T	回り止めなし	オムロン	C1S-703G	-	-	-	-
177	NAC-16G	NBC-16G	CTB-110T	回り止めなし	オムロン	C1S-609G	-	-	-	-
178	NAC-17L	NBC-17L	CVB-212U		オムロン	C1C-001	-	-	-	-
179	NAC-202	NBC-202	D6B-230B		オムロン	C1S-712G	C1S-710R	-	-	-
180	NAC-205	NBC-205	D6B-233B		オムロン	C1S-712G	C1S-712R	-	-	-
181	NAC-211	NBC-211	DEB-240B	回り止めなし	オムロン	C1S-605G	C1S-601R	-	-	-
182	NAC-214	NBC-214	DEB-231B		オムロン	C1S-605R	C1S-605R	-	-	-
183	NAC-218	NBC-218	DEB-231B		オムロン	C1S-703G	C1S-703R	-	-	-
184	NAC-221	NBC-221	D5B-240B	回り止めなし	オムロン	C1S-605G	C1S-601R	-	-	-
185	NAC-222	NBC-222	D9B-230N		オムロン	C1S-712G	C1S-710R	-	-	-
186	NAC-224	NBC-224	D5B-231B		オムロン	C1S-605G	C1S-605R	-	-	-
187	NAC-225	NBC-225	D9B-233N		オムロン	C1S-712G	C1S-712R	-	-	-
188	NAC-228	NBC-228	D5B-231B		オムロン	C1S-703G	C1S-703R	-	-	-
189	NAC-22C	NBC-22C	D9B-233N		オムロン	C1S-717G	C1S-717R	-	-	-
190	NAC-251	NBC-251	CTB-210T	回り止めなし	オムロン	C1S-605G	C1S-601R	-	-	-
191	NAC-253	NBC-253	CUB-210U		オムロン	C1S-712G	C1S-710R	-	-	-
192	NAC-257	NBC-257	CUB-213U		オムロン	C1S-712G	C1S-712R	-	-	-

No.	オールインワン 機器配線付	配線なし	ボックスのみ	備考	スイッチ メーカー	スイッチ1	スイッチ2	スイッチ3	スイッチ4	スイッチ5
193	NAC-25C	NBC-25C	CUB-213U		オムロン	C1S-717G	C1S-717R	-	-	-
194	NAC-265	NBC-265	CTB-211T		オムロン	C1S-605G	C1S-605R	-	-	-
195	NAC-269	NBC-269	CTB-211T		オムロン	C1S-703G	C1S-703R	-	-	-
196	NAC-302	NBC-302	D6B-330B		オムロン	C1S-712G	C1S-712R	C1S-710R	-	-
197	NAC-305	NBC-305	D6B-330B		オムロン	C1S-713G	C1S-713R	C1S-710R	-	-
198	NAC-30B	NBC-30B	D6B-333B		オムロン	C1S-712G	C1S-712R	C1S-712Y	-	-
199	NAC-311	NBC-311	DEB-340B	回り止めなし	オムロン	C1S-605G	C1S-605R	C1S-601R	-	-
200	NAC-317	NBC-317	DEB-331B		オムロン	C1S-605G	C1S-605R	C1S-605Y	-	-
201	NAC-318	NBC-318	DEB-340B	回り止めなし	オムロン	C1S-607G	C1S-607R	C1S-601R	-	-
202	NAC-31D	NBC-31D	DEB-331B		オムロン	C1S-703R	C1S-703R	C1S-703Y	-	-
203	NAC-321	NBC-321	D5B-340B	回り止めなし	オムロン	C1S-605G	C1S-605R	C1S-601R	-	-
204	NAC-322	NBC-322	D9B-330N		オムロン	C1S-712G	C1S-712R	C1S-710R	-	-
205	NAC-325	NBC-325	D9B-330N		オムロン	C1S-713G	C1S-713R	C1S-710R	-	-
206	NAC-327	NBC-327	D5B-331B		オムロン	C1S-605G	C1S-605R	C1S-605Y	-	-
207	NAC-328	NBC-328	D5B-340B	回り止めなし	オムロン	C1S-607G	C1S-607R	C1S-601R	-	-
208	NAC-32B	NBC-32B	D9B-333N		オムロン	C1S-712G	C1S-712R	C1S-712Y	-	-
209	NAC-32D	NBC-32D	D5B-331B		オムロン	C1S-703G	C1S-703R	C1S-703Y	-	-
210	NAC-32G	NBC-32G	D9B-333N		オムロン	C1S-717G	C1S-717R	C1S-717Y	-	-
211	NAC-351	NBC-351	CTB-310T	回り止めなし	オムロン	C1S-605G	C1S-605R	C1S-601R	-	-
212	NAC-353	NBC-353	CUB-310U		オムロン	C1S-712G	C1S-712R	C1S-710R	-	-
213	NAC-355	NBC-355	CTB-310T	回り止めなし	オムロン	C1S-607G	C1S-607R	C1S-601R	-	-
214	NAC-357	NBC-357	CUB-310U		オムロン	C1S-713G	C1S-713R	C1S-710R	-	-
215	NAC-35B	NBC-35B	CUB-313U		オムロン	C1S-712G	C1S-712R	C1S-712Y	-	-
216	NAC-35G	NBC-35G	CUB-313U		オムロン	C1S-717G	C1S-717R	C1S-717Y	-	-
217	NAC-367	NBC-367	CSB-333U		オムロン	C1S-717G	C1S-717R	C1S-710R	-	-
218	NAC-369	NBC-369	CTB-311T		オムロン	C1S-605G	C1S-605R	C1S-605Y	-	-
219	NAC-36D	NBC-36D	CTB-311T		オムロン	C1S-703G	C1S-703R	C1S-703Y	-	-
220	NAC-371	NBC-371	CRB-330U	回り止めなし	オムロン	C1S-605G	C1S-605R	C1S-601R	-	-
221	NAC-373	NBC-373	CRB-420U		オムロン	C1S-605G	C1S-605G	C1S-605R	C1S-605R	-
222	NAC-453	NBC-453	CSB-421U		オムロン	C1S-717G	C1S-717G	C1S-717R	C1S-717R	-
223	NCC-106	NDC-106	D6B-130B		オムロン	C1S-711R	-	-	-	-
224	NCC-10A	NDC-10A	D6B-130B		オムロン	C1S-713G	-	-	-	-

No.	オールインワン 機器配線付	配線なし	ボックスのみ	備考	スイッチ メーカー	スイッチ1	スイッチ2	スイッチ3	スイッチ4	スイッチ5
225	NCC-112	NDC-112	DEB-140B	回り止めなし	オムロン	C1S-603R	-	-	-	-
226	NCC-113	NDC-113	DEB-140B	回り止めなし	オムロン	C1S-604R	-	-	-	-
227	NCC-118	NDC-118	DEB-130B		オムロン	C1S-607G	-	-	-	-
228	NCC-11J	NDC-11J	DEB-130B		オムロン	C1S-704G	-	-	-	-
229	NCC-122	NDC-122	D5B-140B	回り止めなし	オムロン	C1S-603R	-	-	-	-
230	NCC-123	NDC-123	D5B-140B	回り止めなし	オムロン	C1S-604R	-	-	-	-
231	NCC-126	NDC-126	D9B-130N		オムロン	C1S-711R	-	-	-	-
232	NCC-128	NDC-128	D5B-130B		オムロン	C1S-607G	-	-	-	-
233	NCC-12A	NDC-12A	D9B-130N		オムロン	C1S-713G	-	-	-	-
234	NCC-12J	NDC-12J	D5B-130B		オムロン	C1S-704G	-	-	-	-
235	NCC-12M	NDC-12M	D9B-130N		オムロン	C1S-718G	-	-	-	-
236	NCC-152	NDC-152	CTB-110T	回り止めなし	オムロン	C1S-603R	-	-	-	-
237	NCC-154	NDC-154	CTB-110T	回り止めなし	オムロン	C1S-604R	-	-	-	-
238	NCC-156	NDC-156	CUB-110U		オムロン	C1S-711R	-	-	-	-
239	NCC-15A	NDC-15A	CUB-110U		オムロン	C1S-713G	-	-	-	-
240	NCC-15F	NDC-15F	CUB-110U		オムロン	C1S-718G	-	-	-	-
241	NCC-168	NDC-168	CTB-110T	回り止めなし	オムロン	C1S-607G	-	-	-	-
242	NCC-16C	NDC-16C	CTB-110T	回り止めなし	オムロン	C1S-704G	-	-	-	-
243	NCC-203	NDC-203	D6B-230B		オムロン	C1S-713G	C1S-711R	-	-	-
244	NCC-207	NDC-207	D6B-233B		オムロン	C1S-713G	C1S-713R	-	-	-
245	NCC-216	NDC-216	DEB-240B	回り止めなし	オムロン	C1S-607G	C1S-603R	-	-	-
246	NCC-219	NDC-219	DEB-231B		オムロン	C1S-607G	C1S-607R	-	-	-
247	NCC-21A	NDC-21A	DEB-231B		オムロン	C1S-704G	C1S-704R	-	-	-
248	NCC-223	NDC-223	D9B-230N		オムロン	C1S-713G	C1S-711R	-	-	-
249	NCC-226	NDC-226	D5B-240B	回り止めなし	オムロン	C1S-607G	C1S-603R	-	-	-
250	NCC-227	NDC-227	D9B-233N		オムロン	C1S-713G	C1S-713R	-	-	-
251	NCC-229	NDC-229	D5B-231B		オムロン	C1S-607G	C1S-607R	-	-	-
252	NCC-22A	NDC-22A	D5B-231B		オムロン	C1S-704G	C1S-704R	-	-	-
253	NCC-22D	NDC-22D	D9B-233N		オムロン	C1S-718G	C1S-718R	-	-	-
254	NCC-252	NDC-252	CTB-210T	回り止めなし	オムロン	C1S-607G	C1S-603R	-	-	-
255	NCC-254	NDC-254	CUB-210U		オムロン	C1S-713G	C1S-711R	-	-	-
256	NCC-258	NDC-258	CUB-213U		オムロン	C1S-713G	C1S-713R	-	-	-

No.	オールインワン 機器配線付	配線なし	ボックスのみ	備考	スイッチ メーカー	スイッチ1	スイッチ2	スイッチ3	スイッチ4	スイッチ5
257	NCC-25D	NDC-25D	CUB-213U		オムロン	C1S-718G	C1S-718R	-	-	-
258	NCC-266	NDC-266	CTB-211T		オムロン	C1S-607G	C1S-607R	-	-	-
259	NCC-26A	NDC-26A	CTB-211T		オムロン	C1S-704G	C1S-704R	-	-	-
260	NCC-304	NDC-304	D6B-330B		オムロン	C1S-712G	C1S-712R	C1S-711R	-	-
261	NCC-306	NDC-306	D6B-330B		オムロン	C1S-713G	C1S-713R	C1S-711R	-	-
262	NCC-30C	NDC-30C	D6B-333B		オムロン	C1S-713G	C1S-713R	C1S-713Y	-	-
263	NCC-313	NDC-313	DEB-340B	回り止めなし	オムロン	C1S-605G	C1S-605R	C1S-603R	-	-
264	NCC-319	NDC-319	DEB-340B	回り止めなし	オムロン	C1S-607G	C1S-607R	C1S-603R	-	-
265	NCC-31A	NDC-31A	DEB-331B		オムロン	C1S-607G	C1S-607R	C1S-607Y	-	-
266	NCC-31E	NDC-31E	DEB-331B		オムロン	C1S-704G	C1S-704R	C1S-704Y	-	-
267	NCC-321	NDC-321	D5B-370B		オムロン	C1S-262G	C1S-603R	C1S-262G	-	-
268	NCC-323	NDC-323	D5B-340B	回り止めなし	オムロン	C1S-605G	C1S-605R	C1S-603R	-	-
269	NCC-324	NDC-324	D9B-330N		オムロン	C1S-712G	C1S-712R	C1S-711R	-	-
270	NCC-326	NDC-326	D9B-330N		オムロン	C1S-713G	C1S-713R	C1S-711R	-	-
271	NCC-329	NDC-329	D5B-340B	回り止めなし	オムロン	C1S-607G	C1S-607R	C1S-603R	-	-
272	NCC-32A	NDC-32A	D5B-331B		オムロン	C1S-607G	C1S-607R	C1S-607Y	-	-
273	NCC-32C	NDC-32C	D9B-333N		オムロン	C1S-713G	C1S-713R	C1S-713Y	-	-
274	NCC-32E	NDC-32E	D5B-331B		オムロン	C1S-704G	C1S-704R	C1S-704Y	-	-
275	NCC-32H	NDC-32H	D9B-333N		オムロン	C1S-718G	C1S-718R	C1S-718Y	-	-
276	NCC-352	NDC-352	CTB-310T	回り止めなし	オムロン	C1S-605G	C1S-605R	C1S-603R	-	-
277	NCC-354	NDC-354	CUB-310U		オムロン	C1S-712G	C1S-712R	C1S-711R	-	-
278	NCC-356	NDC-356	CTB-310T	回り止めなし	オムロン	C1S-607G	C1S-607R	C1S-603R	-	-
279	NCC-358	NDC-358	CUB-310U		オムロン	C1S-713G	C1S-713R	C1S-711R	-	-
280	NCC-35C	NDC-35C	CUB-313U		オムロン	C1S-713G	C1S-713R	C1S-713Y	-	-
281	NCC-35H	NDC-35H	CUB-313U		オムロン	C1S-718G	C1S-718R	C1S-718Y	-	-
282	NCC-368	NDC-368	CSB-333U		オムロン	C1S-718G	C1S-718R	C1S-711R	-	-
283	NCC-36A	NDC-36A	CTB-311T		オムロン	C1S-607G	C1S-607R	C1S-607Y	-	-
284	NCC-36E	NDC-36E	CTB-311T		オムロン	C1S-704G	C1S-704R	C1S-704Y	-	-
285	NCC-372	NDC-372	CRB-330U	回り止めなし	オムロン	C1S-607G	C1S-607R	C1S-603R	-	-
286	NCC-374	NDC-374	CRB-420U		オムロン	C1S-607G	C1S-607G	C1S-607R	C1S-607R	-
287	NCC-474	NDC-474	CSB-421U		オムロン	C1S-718G	C1S-718G	C1S-718R	C1S-718R	-
288	NEC-102	NFC-102	D6B-130B		IDEC	C1S-722R	-	-	-	-

No.	オールインワン 機器配線付	配線なし	ボックスのみ	備考	スイッチ メーカー	スイッチ1	スイッチ2	スイッチ3	スイッチ4	スイッチ5
289	NEC-105	NFC-105	D6B-130B		IDEC	C1S-725G	-	-	-	-
290	NEC-10D	NFC-10D	D6B-130B		IDEC	C1S-727G	-	-	-	-
291	NEC-10G	NFC-10G	D6B-130B		IDEC	C1S-729G	-	-	-	-
292	NEC-111	NFC-111	DEB-130B		IDEC	C1S-624G	-	-	-	-
293	NEC-112	NFC-112	D8B-130B		IDEC	C1S-722R	-	-	-	-
294	NEC-115	NFC-115	D8B-130B		IDEC	C1S-725G	-	-	-	-
295	NEC-117	NFC-117	DEB-140B	回り止めなし	IDEC	C1S-683R	-	-	-	-
296	NEC-11A	NFC-11A	DEB-140B	回り止めなし	IDEC	C1S-670R	-	-	-	-
297	NEC-11B	NFC-11B	DEB-131B		IDEC	C1S-686G	-	-	-	-
298	NEC-11D	NFC-11D	D8B-130B		IDEC	C1S-727G	-	-	-	-
299	NEC-11F	NFC-11F	DEB-130B		IDEC	C1S-650G	-	-	-	-
300	NEC-11G	NFC-11G	D8B-130B		IDEC	C1S-729G	-	-	-	-
301	NEC-121	NFC-121	D5B-130B		IDEC	C1S-624G	-	-	-	-
302	NEC-122	NFC-122	D9B-130N		IDEC	C1S-722R	-	-	-	-
303	NEC-124	NFC-124	D8B-130B		IDEC	C1S-730R	-	-	-	-
304	NEC-125	NFC-125	D9B-130N		IDEC	C1S-725G	-	-	-	-
305	NEC-126	NFC-126	D8B-130B		IDEC	C1S-730G	-	-	-	-
306	NEC-127	NFC-127	D5B-140B	回り止めなし	IDEC	C1S-683R	-	-	-	-
307	NEC-12A	NFC-12A	D5B-140B	回り止めなし	IDEC	C1S-670R	-	-	-	-
308	NEC-12B	NFC-12B	D5B-131B		IDEC	C1S-686G	-	-	-	-
309	NEC-12D	NFC-12D	D9B-130N		IDEC	C1S-727G	-	-	-	-
310	NEC-12F	NFC-12F	D5B-130B		IDEC	C1S-650G	-	-	-	-
311	NEC-12G	NFC-12G	D9B-130N		IDEC	C1S-729G	-	-	-	-
312	NEC-151	NFC-151	CTB-110T	回り止めなし	IDEC	C1S-683R	-	-	-	-
313	NEC-153	NFC-153	CTB-110T	回り止めなし	IDEC	C1S-670R	-	-	-	-
314	NEC-155	NFC-155	CUB-110U		IDEC	C1S-722R	-	-	-	-
315	NEC-159	NFC-159	CUB-110U		IDEC	C1S-725G	-	-	-	-
316	NEC-15D	NFC-15D	CUB-110U		IDEC	C1S-727G	-	-	-	-
317	NEC-15J	NFC-15J	CUB-110U		IDEC	C1S-729G	-	-	-	-
318	NEC-167	NFC-167	CTB-110T	回り止めなし	IDEC	C1S-624G	-	-	-	-
319	NEC-16B	NFC-16B	CTB-112T		IDEC	C1S-686G	-	-	-	-
320	NEC-16G	NFC-16G	CTB-110T	回り止めなし	IDEC	C1S-650G	-	-	-	-

No.	オールインワン 機器配線付	配線なし	ボックスのみ	備考	スイッチ メーカー	スイッチ1	スイッチ2	スイッチ3	スイッチ4	スイッチ5
321	NEC-207	NFC-207	D6B-233B		IDEC	C1S-725G	C1S-725R	-	-	-
322	NEC-209	NFC-209	D6B-230B		IDEC	C1S-725G	C1S-722R	-	-	-
323	NEC-20B	NFC-20B	D6B-233B		IDEC	C1S-727G	C1S-727R	-	-	-
324	NEC-212	NFC-212	DEB-240B	回り止めなし	IDEC	C1S-624G	C1S-683R	-	-	-
325	NEC-215	NFC-215	DEB-231B		IDEC	C1S-624G	C1S-624R	-	-	-
326	NEC-217	NFC-217	D8B-233B		IDEC	C1S-725G	C1S-725R	-	-	-
327	NEC-219	NFC-219	D8B-230B		IDEC	C1S-725G	C1S-722R	-	-	-
328	NEC-21A	NFC-21A	DEB-232B		IDEC	C1S-686G	C1S-686R	-	-	-
329	NEC-21B	NFC-21B	D8B-233B		IDEC	C1S-727G	C1S-727R	-	-	-
330	NEC-222	NFC-222	D5B-240B	回り止めなし	IDEC	C1S-624G	C1S-683R	-	-	-
331	NEC-225	NFC-225	D5B-231B		IDEC	C1S-624G	C1S-624R	-	-	-
332	NEC-226	NFC-226	D8B-240B		IDEC	C1S-730R	C1S-730G	-	-	-
333	NEC-227	NFC-227	D9B-233N		IDEC	C1S-725G	C1S-725R	-	-	-
334	NEC-229	NFC-229	D9B-230N		IDEC	C1S-725G	C1S-722R	-	-	-
335	NEC-22A	NFC-22A	D5B-232B		IDEC	C1S-686G	C1S-686R	-	-	-
336	NEC-22B	NFC-22B	D9B-233N		IDEC	C1S-727G	C1S-727R	-	-	-
337	NEC-251	NFC-251	CTB-210T	回り止めなし	IDEC	C1S-624G	C1S-683R	-	-	-
338	NEC-253	NFC-253	CUB-210U		IDEC	C1S-725G	C1S-722R	-	-	-
339	NEC-257	NFC-257	CUB-213U		IDEC	C1S-725G	C1S-725R	-	-	-
340	NEC-25B	NFC-25B	CUB-213U		IDEC	C1S-727G	C1S-727R	-	-	-
341	NEC-265	NFC-265	CTB-211T		IDEC	C1S-624G	C1S-624R	-	-	-
342	NEC-269	NFC-269	CTB-212T		IDEC	C1S-686G	C1S-686R	-	-	-
343	NEC-305	NFC-305	D6B-330B		IDEC	C1S-725G	C1S-725R	C1S-722R	-	-
344	NEC-308	NFC-308	D6B-330B		IDEC	C1S-726G	C1S-726R	C1S-722R	-	-
345	NEC-30B	NFC-30B	D6B-333B		IDEC	C1S-725G	C1S-725R	C1S-725Y	-	-
346	NEC-30F	NFC-30F	D6B-333B		IDEC	C1S-727G	C1S-727R	C1S-727Y	-	-
347	NEC-312	NFC-312	DEB-340B	回り止めなし	IDEC	C1S-624G	C1S-624R	C1S-683R	-	-
348	NEC-315	NFC-315	D8B-330B		IDEC	C1S-725G	C1S-725R	C1S-722R	-	-
349	NEC-316	NFC-316	DEB-331B		IDEC	C1S-624G	C1S-624R	C1S-624Y	-	-
350	NEC-318	NFC-318	D8B-330B		IDEC	C1S-726G	C1S-726R	C1S-722R	-	-
351	NEC-319	NFC-319	DEB-340B	回り止めなし	IDEC	C1S-627G	C1S-627R	C1S-683R	-	-
352	NEC-31B	NFC-31B	D8B-333B		IDEC	C1S-725G	C1S-725R	C1S-725Y	-	-

No.	オールインワン 機器配線付	配線なし	ボックスのみ	備考	スイッチ メーカー	スイッチ1	スイッチ2	スイッチ3	スイッチ4	スイッチ5
353	NEC-31D	NFC-31D	DEB-332B		IDEC	C1S-686G	C1S-686R	C1S-686Y	-	-
354	NEC-31F	NFC-31F	D8B-333B		IDEC	C1S-727G	C1S-727R	C1S-727Y	-	-
355	NEC-322	NFC-322	D5B-340B	回り止めなし	IDEC	C1S-624G	C1S-624R	C1S-683R	-	-
356	NEC-325	NFC-325	D9B-330N		IDEC	C1S-725G	C1S-725R	C1S-722R	-	-
357	NEC-326	NFC-326	D5B-331B		IDEC	C1S-624G	C1S-624R	C1S-624Y	-	-
358	NEC-328	NFC-328	D9B-330N		IDEC	C1S-726G	C1S-726R	C1S-722R	-	-
359	NEC-329	NFC-329	D5B-340B	回り止めなし	IDEC	C1S-627G	C1S-627R	C1S-683R	-	-
360	NEC-32B	NFC-32B	D9B-333N		IDEC	C1S-725G	C1S-725R	C1S-725Y	-	-
361	NEC-32D	NFC-32D	D5B-332B		IDEC	C1S-686G	C1S-686R	C1S-686Y	-	-
362	NEC-32F	NFC-32F	D9B-333N		IDEC	C1S-727G	C1S-727R	C1S-727Y	-	-
363	NEC-351	NFC-351	CTB-310T	回り止めなし	IDEC	C1S-624G	C1S-624R	C1S-683R	-	-
364	NEC-353	NFC-353	CUB-310U		IDEC	C1S-725G	C1S-725R	C1S-722R	-	-
365	NEC-355	NFC-355	CTB-310T	回り止めなし	IDEC	C1S-627G	C1S-627R	C1S-683R	-	-
366	NEC-357	NFC-357	CUB-310U		IDEC	C1S-726G	C1S-726R	C1S-722R	-	-
367	NEC-35B	NFC-35B	CUB-313U		IDEC	C1S-725G	C1S-725R	C1S-725Y	-	-
368	NEC-35F	NFC-35F	CUB-313U		IDEC	C1S-727G	C1S-727R	C1S-727Y	-	-
369	NEC-365	NFC-365	CSB-332U		IDEC	C1S-727G	C1S-727R	C1S-722R	-	-
370	NEC-367	NFC-367	CSB-420U		IDEC	C1S-727G	C1S-727G	C1S-727R	C1S-727R	-
371	NEC-369	NFC-369	CTB-311T		IDEC	C1S-624G	C1S-624R	C1S-624Y	-	-
372	NEC-36D	NFC-36D	CTB-312T		IDEC	C1S-686G	C1S-686R	C1S-686Y	-	-
373	NEC-375	NFC-375	CRB-330U	回り止めなし	IDEC	C1S-624G	C1S-624R	C1S-683R	-	-
374	NEC-377	NFC-377	CRB-420U		IDEC	C1S-624G	C1S-624G	C1S-624R	C1S-624R	-
375	NGC-103	NHC-103	D6B-130B		IDEC	C1S-723R	-	-	-	-
376	NGC-106	NHC-106	D6B-130B		IDEC	C1S-726G	-	-	-	-
377	NGC-10E	NHC-10E	D6B-130B		IDEC	C1S-728G	-	-	-	-
378	NGC-113	NHC-113	D8B-130B		IDEC	C1S-723R	-	-	-	-
379	NGC-114	NHC-114	DEB-130B		IDEC	C1S-627G	-	-	-	-
380	NGC-116	NHC-116	D8B-130B		IDEC	C1S-726G	-	-	-	-
381	NGC-118	NHC-118	DEB-140B	回り止めなし	IDEC	C1S-685R	-	-	-	-
382	NGC-119	NHC-119	DEB-140B	回り止めなし	IDEC	C1S-684R	-	-	-	-
383	NGC-11C	NHC-11C	DEB-131B		IDEC	C1S-687G	-	-	-	-
384	NGC-11E	NHC-11E	D8B-130B		IDEC	C1S-728G	-	-	-	-

No.	オールインワン 機器配線付	配線なし	ボックスのみ	備考	スイッチ メーカー	スイッチ1	スイッチ2	スイッチ3	スイッチ4	スイッチ5
385	NGC-122	NHC-122	D6B-140B		IDEC	C1S-724R	-	-	-	-
386	NGC-123	NHC-123	D9B-130N		IDEC	C1S-723R	-	-	-	-
387	NGC-124	NHC-124	D5B-130B		IDEC	C1S-627G	-	-	-	-
388	NGC-125	NHC-125	D6B-130B		IDEC	C1S-724R	-	-	-	-
389	NGC-126	NHC-126	D9B-130N		IDEC	C1S-726G	-	-	-	-
390	NGC-128	NHC-128	D5B-140B	回り止めなし	IDEC	C1S-685R	-	-	-	-
391	NGC-129	NHC-129	D5B-140B	回り止めなし	IDEC	C1S-684R	-	-	-	-
392	NGC-12C	NHC-12C	D5B-131B		IDEC	C1S-687G	-	-	-	-
393	NGC-12E	NHC-12E	D9B-130N		IDEC	C1S-728G	-	-	-	-
394	NGC-152	NHC-152	CTB-110T	回り止めなし	IDEC	C1S-685R	-	-	-	-
395	NGC-154	NHC-154	CTB-110T	回り止めなし	IDEC	C1S-684R	-	-	-	-
396	NGC-156	NHC-156	CUB-110U		IDEC	C1S-723R	-	-	-	-
397	NGC-15A	NHC-15A	CUB-110U		IDEC	C1S-726G	-	-	-	-
398	NGC-15E	NHC-15E	CUB-110U		IDEC	C1S-728G	-	-	-	-
399	NGC-168	NHC-168	CTB-110T	回り止めなし	IDEC	C1S-627G	-	-	-	-
400	NGC-16C	NHC-16C	CTB-112T		IDEC	C1S-687G	-	-	-	-
401	NGC-204	NHC-204	D6B-230B		IDEC	C1S-726G	C1S-723R	-	-	-
402	NGC-208	NHC-208	D6B-233B		IDEC	C1S-726G	C1S-726R	-	-	-
403	NGC-20C	NHC-20C	D6B-233B		IDEC	C1S-728G	C1S-728R	-	-	-
404	NGC-211	NHC-211	DEB-231B		IDEC	C1S-627G	C1S-627R	-	-	-
405	NGC-213	NHC-213	DEB-232B		IDEC	C1S-687G	C1S-687R	-	-	-
406	NGC-214	NHC-214	D8B-230B		IDEC	C1S-726G	C1S-723R	-	-	-
407	NGC-216	NHC-216	DEB-240B	回り止めなし	IDEC	C1S-627G	C1S-685R	-	-	-
408	NGC-218	NHC-218	D8B-233B		IDEC	C1S-726G	C1S-726R	-	-	-
409	NGC-21C	NHC-21C	D8B-233B		IDEC	C1S-728G	C1S-728R	-	-	-
410	NGC-221	NHC-221	D5B-231B		IDEC	C1S-627G	C1S-627R	-	-	-
411	NGC-223	NHC-223	D5B-232B		IDEC	C1S-687G	C1S-687R	-	-	-
412	NGC-224	NHC-224	D9B-230N		IDEC	C1S-726G	C1S-723R	-	-	-
413	NGC-226	NHC-226	D5B-240B	回り止めなし	IDEC	C1S-627G	C1S-685R	-	-	-
414	NGC-228	NHC-228	D9B-233N		IDEC	C1S-726G	C1S-726R	-	-	-
415	NGC-22C	NHC-22C	D9B-233N		IDEC	C1S-728G	C1S-728R	-	-	-
416	NGC-252	NHC-252	CTB-210T	回り止めなし	IDEC	C1S-627G	C1S-685R	-	-	-

No.	オールインワン 機器配線付	配線なし	ボックスのみ	備考	スイッチ メーカー	スイッチ1	スイッチ2	スイッチ3	スイッチ4	スイッチ5
417	NGC-254	NHC-254	CUB-210U		IDEC	C1S-726G	C1S-723R	-	-	-
418	NGC-258	NHC-258	CUB-213U		IDEC	C1S-726G	C1S-726R	-	-	-
419	NGC-25C	NHC-25C	CUB-213U		IDEC	C1S-728G	C1S-728R	-	-	-
420	NGC-266	NHC-266	CTB-211T		IDEC	C1S-627G	C1S-627R	-	-	-
421	NGC-26A	NHC-26A	CTB-212T		IDEC	C1S-687G	C1S-687R	-	-	-
422	NGC-307	NHC-307	D6B-330B		IDEC	C1S-725G	C1S-725R	C1S-723R	-	-
423	NGC-30A	NHC-30A	D6B-330B		IDEC	C1S-726G	C1S-726R	C1S-723R	-	-
424	NGC-30C	NHC-30C	D6B-333B		IDEC	C1S-726G	C1S-726R	C1S-726Y	-	-
425	NGC-30G	NHC-30G	D6B-333B		IDEC	C1S-728G	C1S-728R	C1S-728Y	-	-
426	NGC-311	NHC-311	DEB-340B	回り止めなし	IDEC	C1S-627G	C1S-627R	C1S-685R	-	-
427	NGC-313	NHC-313	DEB-331B		IDEC	C1S-627G	C1S-627R	C1S-627Y	-	-
428	NGC-314	NHC-314	DEB-340B	回り止めなし	IDEC	C1S-624G	C1S-624R	C1S-685R	-	-
429	NGC-317	NHC-317	D8B-330B		IDEC	C1S-725G	C1S-725R	C1S-723R	-	-
430	NGC-31A	NHC-31A	D8B-330B		IDEC	C1S-726G	C1S-726R	C1S-723R	-	-
431	NGC-31C	NHC-31C	D8B-333B		IDEC	C1S-726G	C1S-726R	C1S-726Y	-	-
432	NGC-31E	NHC-31E	DEB-332B		IDEC	C1S-687G	C1S-687R	C1S-687Y	-	-
433	NGC-31G	NHC-31G	D8B-333B		IDEC	C1S-728G	C1S-728R	C1S-728Y	-	-
434	NGC-321	NHC-321	D5B-340B	回り止めなし	IDEC	C1S-627G	C1S-627R	C1S-685R	-	-
435	NGC-322	NHC-322	D9B-370N		IDEC	C1S-205G	C1S-723R	C1S-205G	-	-
436	NGC-323	NHC-323	D5B-331B		IDEC	C1S-627G	C1S-627R	C1S-627Y	-	-
437	NGC-324	NHC-324	D5B-340B	回り止めなし	IDEC	C1S-624G	C1S-624R	C1S-685R	-	-
438	NGC-327	NHC-327	D9B-330N		IDEC	C1S-725G	C1S-725R	C1S-723R	-	-
439	NGC-32A	NHC-32A	D9B-330N		IDEC	C1S-726G	C1S-726R	C1S-723R	-	-
440	NGC-32C	NHC-32C	D9B-333N		IDEC	C1S-726G	C1S-726R	C1S-726Y	-	-
441	NGC-32E	NHC-32E	D5B-332B		IDEC	C1S-687G	C1S-687R	C1S-687Y	-	-
442	NGC-32G	NHC-32G	D9B-333N		IDEC	C1S-728G	C1S-728R	C1S-728Y	-	-
443	NGC-352	NHC-352	CTB-310T	回り止めなし	IDEC	C1S-624G	C1S-624R	C1S-685R	-	-
444	NGC-354	NHC-354	CUB-310U		IDEC	C1S-725G	C1S-725R	C1S-723R	-	-
445	NGC-356	NHC-356	CTB-310T	回り止めなし	IDEC	C1S-627G	C1S-627R	C1S-685R	-	-
446	NGC-358	NHC-358	CUB-310U		IDEC	C1S-726G	C1S-726R	C1S-723R	-	-
447	NGC-35C	NHC-35C	CUB-313U		IDEC	C1S-726G	C1S-726R	C1S-726Y	-	-
448	NGC-35G	NHC-35G	CUB-313U		IDEC	C1S-728G	C1S-728R	C1S-728Y	-	-

No.	オールインワン 機器配線付	配線なし	ボックスのみ	備考	スイッチ メーカー	スイッチ1	スイッチ2	スイッチ3	スイッチ4	スイッチ5
449	NGC-366	NHC-366	CSB-332U		IDEC	C1S-728G	C1S-728R	C1S-723R	-	-
450	NGC-368	NHC-368	CSB-420U		IDEC	C1S-728G	C1S-728G	C1S-728R	C1S-728R	-
451	NGC-36A	NHC-36A	CTB-311T		IDEC	C1S-627G	C1S-627R	C1S-627Y	-	-
452	NGC-36E	NHC-36E	CTB-312T		IDEC	C1S-687G	C1S-687R	C1S-687Y	-	-
453	NGC-376	NHC-376	CRB-330U	回り止めなし	IDEC	C1S-627G	C1S-627R	C1S-685R	-	-
454	NGC-378	NHC-378	CRB-420U		IDEC	C1S-627G	C1S-627G	C1S-627R	C1S-627R	-
455	NJC-101	NKC-101	DEB-140B	回り止めなし	富士	C1S-754R	-	-	-	-
456	NJC-105	NKC-105	DEB-130B		富士	C1S-634G	-	-	-	-
457	NJC-107	NKC-107	DEB-130B		富士	C1S-635G	-	-	-	-
458	NJC-109	NKC-109	DEB-130B		富士	C1S-638G	-	-	-	-
459	NJC-10A	NKC-10A	D6B-130B		富士	C1S-231R	-	-	-	-
460	NJC-10C	NKC-10C	D6B-130B		富士	C1S-246G	-	-	-	-
461	NJC-10E	NKC-10E	D6B-130B		富士	C1S-233G	-	-	-	-
462	NJC-10G	NKC-10G	D6B-130B		富士	C1S-238G	-	-	-	-
463	NJC-111	NKC-111	D4B-140B	回り止めなし	富士	C1S-757R	-	-	-	-
464	NJC-113	NKC-113	D4B-140B	回り止めなし	富士	C1S-759R	-	-	-	-
465	NJC-115	NKC-115	D4B-130B		富士	C1S-761G	-	-	-	-
466	NJC-117	NKC-117	D4B-130B		富士	C1S-762G	-	-	-	-
467	NJC-119	NKC-119	D4B-130B		富士	C1S-765G	-	-	-	-
468	NJC-11A	NKC-11A	D8B-130B		富士	C1S-231R	-	-	-	-
469	NJC-11C	NKC-11C	D8B-130B		富士	C1S-246G	-	-	-	-
470	NJC-11E	NKC-11E	D8B-130B		富士	C1S-233G	-	-	-	-
471	NJC-11G	NKC-11G	D8B-130B		富士	C1S-238G	-	-	-	-
472	NJC-121	NKC-121	D5B-140B	回り止めなし	富士	C1S-757R	-	-	-	-
473	NJC-123	NKC-123	D5B-140B	回り止めなし	富士	C1S-759R	-	-	-	-
474	NJC-125	NKC-125	D5B-130B		富士	C1S-761G	-	-	-	-
475	NJC-127	NKC-127	D5B-130B		富士	C1S-762G	-	-	-	-
476	NJC-129	NKC-129	D5B-130B		富士	C1S-765G	-	-	-	-
477	NJC-12A	NKC-12A	D9B-130N		富士	C1S-231R	-	-	-	-
478	NJC-12C	NKC-12C	D9B-130N		富士	C1S-246G	-	-	-	-
479	NJC-12E	NKC-12E	D9B-130N		富士	C1S-233G	-	-	-	-
480	NJC-12G	NKC-12G	D9B-130N		富士	C1S-238G	-	-	-	-

No.	オールインワン 機器配線付	配線なし	ボックスのみ	備考	スイッチ メーカー	スイッチ1	スイッチ2	スイッチ3	スイッチ4	スイッチ5
481	NJC-201	NKC-201	DEB-240B	回り止めなし	富士	C1S-634G	C1S-754R	-	-	-
482	NJC-203	NKC-203	DEB-231B		富士	C1S-634G	C1S-634R	-	-	-
483	NJC-205	NKC-205	DEB-231B		富士	C1S-635G	C1S-635R	-	-	-
484	NJC-207	NKC-207	D6B-230B		富士	C1S-246G	C1S-231R	-	-	-
485	NJC-209	NKC-209	D6B-233B		富士	C1S-246G	C1S-246R	-	-	-
486	NJC-20B	NKC-20B	D6B-233B		富士	C1S-233G	C1S-233R	-	-	-
487	NJC-211	NKC-211	D4B-240B	回り止めなし	富士	C1S-761G	C1S-757R	-	-	-
488	NJC-213	NKC-213	D4B-231B		富士	C1S-761G	C1S-761R	-	-	-
489	NJC-215	NKC-215	D4B-231B		富士	C1S-762G	C1S-762R	-	-	-
490	NJC-217	NKC-217	D8B-230B		富士	C1S-246G	C1S-231R	-	-	-
491	NJC-219	NKC-219	D8B-233B		富士	C1S-246G	C1S-246R	-	-	-
492	NJC-21B	NKC-21B	D8B-233B		富士	C1S-233G	C1S-233R	-	-	-
493	NJC-221	NKC-221	D5B-240B	回り止めなし	富士	C1S-761G	C1S-757R	-	-	-
494	NJC-223	NKC-223	D5B-231B		富士	C1S-761G	C1S-761R	-	-	-
495	NJC-225	NKC-225	D5B-231B		富士	C1S-762G	C1S-762R	-	-	-
496	NJC-227	NKC-227	D9B-230N		富士	C1S-246G	C1S-231R	-	-	-
497	NJC-229	NKC-229	D9B-233N		富士	C1S-246G	C1S-246R	-	-	-
498	NJC-22B	NKC-22B	D9B-233N		富士	C1S-233G	C1S-233R	-	-	-
499	NJC-301	NKC-301	DEB-340B	回り止めなし	富士	C1S-634G	C1S-634R	C1S-754R	-	-
500	NJC-303	NKC-303	DEB-340B	回り止めなし	富士	C1S-636G	C1S-636R	C1S-754R	-	-
501	NJC-305	NKC-305	DEB-331B		富士	C1S-634G	C1S-634R	C1S-634Y	-	-
502	NJC-307	NKC-307	DEB-331B		富士	C1S-635G	C1S-635R	C1S-635Y	-	-
503	NJC-309	NKC-309	D6B-330B		富士	C1S-246G	C1S-246R	C1S-231R	-	-
504	NJC-30B	NKC-30B	D6B-330B		富士	C1S-247G	C1S-247R	C1S-231R	-	-
505	NJC-30D	NKC-30D	D6B-333B		富士	C1S-246G	C1S-246R	C1S-246Y	-	-
506	NJC-30F	NKC-30F	D6B-333B		富士	C1S-233G	C1S-233R	C1S-233Y	-	-
507	NJC-311	NKC-311	D4B-340B	回り止めなし	富士	C1S-761G	C1S-761R	C1S-757R	-	-
508	NJC-313	NKC-313	D4B-340B	回り止めなし	富士	C1S-763G	C1S-763R	C1S-757R	-	-
509	NJC-315	NKC-315	D4B-331B		富士	C1S-761G	C1S-761R	C1S-761Y	-	-
510	NJC-317	NKC-317	D4B-331B		富士	C1S-762G	C1S-762R	C1S-762Y	-	-
511	NJC-319	NKC-319	D8B-330B		富士	C1S-246G	C1S-246R	C1S-231R	-	-
512	NJC-31B	NKC-31B	D8B-330B		富士	C1S-247G	C1S-247R	C1S-231R	-	-

No.	オールインワン 機器配線付	配線なし	ボックスのみ	備考	スイッチ メーカー	スイッチ1	スイッチ2	スイッチ3	スイッチ4	スイッチ5
513	NJC-31D	NKC-31D	D8B-333B		富士	C1S-246G	C1S-246R	C1S-246Y	-	-
514	NJC-31F	NKC-31F	D8B-333B		富士	C1S-233G	C1S-233R	C1S-233Y	-	-
515	NJC-321	NKC-321	D5B-340B	回り止めなし	富士	C1S-761G	C1S-761R	C1S-757R	-	-
516	NJC-323	NKC-323	D5B-340B	回り止めなし	富士	C1S-763G	C1S-763R	C1S-757R	-	-
517	NJC-325	NKC-325	D5B-331B		富士	C1S-761G	C1S-761R	C1S-761Y	-	-
518	NJC-327	NKC-327	D5B-331B		富士	C1S-762G	C1S-762R	C1S-762Y	-	-
519	NJC-329	NKC-329	D9B-330N		富士	C1S-246G	C1S-246R	C1S-231R	-	-
520	NJC-32B	NKC-32B	D9B-330N		富士	C1S-247G	C1S-247R	C1S-231R	-	-
521	NJC-32D	NKC-32D	D9B-333N		富士	C1S-246G	C1S-246R	C1S-246Y	-	-
522	NJC-32F	NKC-32F	D9B-333N		富士	C1S-233G	C1S-233R	C1S-233Y	-	-
523	NLC-102	NMC-102	DEB-140B	回り止めなし	富士	C1S-752R	-	-	-	-
524	NLC-104	NMC-104	DEB-140B	回り止めなし	富士	C1S-751R	-	-	-	-
525	NLC-106	NMC-106	DEB-130B		富士	C1S-636G	-	-	-	-
526	NLC-108	NMC-108	DEB-130B		富士	C1S-637G	-	-	-	-
527	NLC-10B	NMC-10B	D6B-130B		富士	C1S-232R	-	-	-	-
528	NLC-10D	NMC-10D	D6B-130B		富士	C1S-247G	-	-	-	-
529	NLC-10F	NMC-10F	D6B-130B		富士	C1S-237G	-	-	-	-
530	NLC-112	NMC-112	D4B-140B	回り止めなし	富士	C1S-758R	-	-	-	-
531	NLC-114	NMC-114	D4B-140B	回り止めなし	富士	C1S-760R	-	-	-	-
532	NLC-116	NMC-116	D4B-130B		富士	C1S-763G	-	-	-	-
533	NLC-118	NMC-118	D4B-130B		富士	C1S-764G	-	-	-	-
534	NLC-11B	NMC-11B	D8B-130B		富士	C1S-232R	-	-	-	-
535	NLC-11D	NMC-11D	D8B-130B		富士	C1S-247G	-	-	-	-
536	NLC-11F	NMC-11F	D8B-130B		富士	C1S-237G	-	-	-	-
537	NLC-122	NMC-122	D5B-140B	回り止めなし	富士	C1S-758R	-	-	-	-
538	NLC-124	NMC-124	D5B-140B	回り止めなし	富士	C1S-760R	-	-	-	-
539	NLC-126	NMC-126	D5B-130B		富士	C1S-763G	-	-	-	-
540	NLC-128	NMC-128	D5B-130B		富士	C1S-764G	-	-	-	-
541	NLC-12B	NMC-12B	D9B-130N		富士	C1S-232R	-	-	-	-
542	NLC-12D	NMC-12D	D9B-130N		富士	C1S-247G	-	-	-	-
543	NLC-12F	NMC-12F	D9B-130N		富士	C1S-237G	-	-	-	-
544	NLC-202	NMC-202	DEB-240B	回り止めなし	富士	C1S-636G	C1S-752R	-	-	-

No.	オールインワン 機器配線付	配線なし	ボックスのみ	備考	スイッチ メーカー	スイッチ1	スイッチ2	スイッチ3	スイッチ4	スイッチ5
545	NLC-204	NMC-204	DEB-231B		富士	C1S-636G	C1S-636R	-	-	-
546	NLC-206	NMC-206	DEB-231B		富士	C1S-637G	C1S-637R	-	-	-
547	NLC-208	NMC-208	D6B-230B		富士	C1S-247G	C1S-232R	-	-	-
548	NLC-20A	NMC-20A	D6B-233B		富士	C1S-247G	C1S-247R	-	-	-
549	NLC-20C	NMC-20C	D6B-233B		富士	C1S-237G	C1S-237R	-	-	-
550	NLC-212	NMC-212	D4B-240B	回り止めなし	富士	C1S-763G	C1S-758R	-	-	-
551	NLC-214	NMC-214	D4B-231B		富士	C1S-763G	C1S-763R	-	-	-
552	NLC-216	NMC-216	D4B-231B		富士	C1S-764G	C1S-764R	-	-	-
553	NLC-218	NMC-218	D8B-230B		富士	C1S-247G	C1S-232R	-	-	-
554	NLC-21A	NMC-21A	D8B-233B		富士	C1S-247G	C1S-247R	-	-	-
555	NLC-21C	NMC-21C	D8B-233B		富士	C1S-237G	C1S-237R	-	-	-
556	NLC-222	NMC-222	D5B-240B	回り止めなし	富士	C1S-763G	C1S-758R	-	-	-
557	NLC-224	NMC-224	D5B-231B		富士	C1S-763G	C1S-763R	-	-	-
558	NLC-226	NMC-226	D5B-231B		富士	C1S-764G	C1S-764R	-	-	-
559	NLC-228	NMC-228	D9B-230N		富士	C1S-247G	C1S-232R	-	-	-
560	NLC-22A	NMC-22A	D9B-233N		富士	C1S-247G	C1S-247R	-	-	-
561	NLC-22C	NMC-22C	D9B-233N		富士	C1S-237G	C1S-237R	-	-	-
562	NLC-302	NMC-302	DEB-340B	回り止めなし	富士	C1S-634G	C1S-634R	C1S-752R	-	-
563	NLC-304	NMC-304	DEB-340B	回り止めなし	富士	C1S-636G	C1S-636R	C1S-752R	-	-
564	NLC-306	NMC-306	DEB-331B		富士	C1S-636G	C1S-636R	C1S-636Y	-	-
565	NLC-308	NMC-308	DEB-331B		富士	C1S-637G	C1S-637R	C1S-637Y	-	-
566	NLC-30A	NMC-30A	D6B-330B		富士	C1S-246G	C1S-246R	C1S-232R	-	-
567	NLC-30C	NMC-30C	D6B-330B		富士	C1S-247G	C1S-247R	C1S-232R	-	-
568	NLC-30E	NMC-30E	D6B-333B		富士	C1S-247G	C1S-247R	C1S-247Y	-	-
569	NLC-30G	NMC-30G	D6B-333B		富士	C1S-237G	C1S-237R	C1S-237Y	-	-
570	NLC-312	NMC-312	D4B-340B	回り止めなし	富士	C1S-761G	C1S-761R	C1S-758R	-	-
571	NLC-314	NMC-314	D4B-340B	回り止めなし	富士	C1S-763G	C1S-763R	C1S-758R	-	-
572	NLC-316	NMC-316	D4B-331B		富士	C1S-763G	C1S-763R	C1S-763Y	-	-
573	NLC-318	NMC-318	D4B-331B		富士	C1S-764G	C1S-764R	C1S-764Y	-	-
574	NLC-31A	NMC-31A	D8B-330B		富士	C1S-246G	C1S-246R	C1S-232R	-	-
575	NLC-31C	NMC-31C	D8B-330B		富士	C1S-247G	C1S-247R	C1S-232R	-	-
576	NLC-31E	NMC-31E	D8B-333B		富士	C1S-247G	C1S-247R	C1S-247Y	-	-

No.	オールインワン 機器配線付	配線なし	ボックスのみ	備考	スイッチ メーカー	スイッチ1	スイッチ2	スイッチ3	スイッチ4	スイッチ5
577	NLC-31G	NMC-31G	D8B-333B		富士	C1S-237G	C1S-237R	C1S-237Y	-	-
578	NLC-322	NMC-322	D5B-340B	回り止めなし	富士	C1S-761G	C1S-761R	C1S-758R	-	-
579	NLC-324	NMC-324	D5B-340B	回り止めなし	富士	C1S-763G	C1S-763R	C1S-758R	-	-
580	NLC-326	NMC-326	D5B-331B		富士	C1S-763G	C1S-763R	C1S-763Y	-	-
581	NLC-328	NMC-328	D5B-331B		富士	C1S-764G	C1S-764R	C1S-764Y	-	-
582	NLC-32A	NMC-32A	D9B-330N		富士	C1S-246G	C1S-246R	C1S-232R	-	-
583	NLC-32C	NMC-32C	D9B-330N		富士	C1S-247G	C1S-247R	C1S-232R	-	-
584	NLC-32E	NMC-32E	D9B-333N		富士	C1S-247G	C1S-247R	C1S-247Y	-	-
585	NLC-32G	NMC-32G	D9B-333N		富士	C1S-237G	C1S-237R	C1S-237Y	-	-
586	NVC-102	-	-		NKK	C1S-402G	-	-	-	-
587	NVC-102G	-	-		NKK	C1S-402G	-	-	-	-
588	NVC-103	-	-		NKK	C1S-402R	-	-	-	-
589	NVC-103G	-	-		NKK	C1S-402R	-	-	-	-
590	NVC-202	-	-		NKK	C1S-402G	C1S-402R	-	-	-
591	NVC-202G	-	-		NKK	C1S-402G	C1S-402R	-	-	-
592	NXC-101	-	-		NKK	C1S-401R	-	-	-	-
593	NXC-101G	-	-		NKK	C1S-401R	-	-	-	-
594	NXC-201	-	-		NKK	C1S-402G	C1S-401R	-	-	-
595	NXC-201G	-	-		NKK	C1S-402G	C1S-401R	-	-	-
596	NXC-301	-	-		NKK	C1S-402G	C1S-402R	C1S-401R	-	-
597	NXC-301G	-	-		NKK	C1S-402G	C1S-402R	C1S-401R	-	-
598	NXC-401	-	-		NKK	C1S-402G	C1S-402R	C1S-402Y	C1S-401R	-
599	NXC-401G	-	-		NKK	C1S-402G	C1S-402R	C1S-402Y	C1S-401R	-
600	NXC-501	-	-		NKK	C1S-402G	C1S-402G	C1S-402R	C1S-402Y	C1S-401R
601	NXC-501G	-	-		NKK	C1S-402G	C1S-402G	C1S-402R	C1S-402Y	C1S-401R
602	R4C-101	-	R4B-101		オムロン	C1S-601R	-	-	-	-
603	R4C-102	-	R4B-101		オムロン	C1S-603R	-	-	-	-
604	R4C-103	-	R4B-103		オムロン	C1S-605G	-	-	-	-
605	R4C-104	-	R4B-103		オムロン	C1S-607G	-	-	-	-
606	R4C-105	-	R4B-102		IDEC	C1S-658R	-	-	-	-
607	R4C-106	-	R4B-102		IDEC	C1S-657R	-	-	-	-
608	R4C-107	-	R4B-104		IDEC	C1S-655G	-	-	-	-

No.	オールインワン 機器配線付	配線なし	ボックスのみ	備考	スイッチ メーカー	スイッチ1	スイッチ2	スイッチ3	スイッチ4	スイッチ5
609	R4C-108	-	R4B-104		IDEC	C1S-656G	-	-	-	-
610	R4C-109	-	R4B-102		富士	C1S-757R	-	-	-	-
611	R4C-110	-	R4B-102		富士	C1S-758R	-	-	-	-
612	R4C-111	-	R4B-104		富士	C1S-761G	-	-	-	-
613	R4C-112	-	R4B-104		富士	C1S-763G	-	-	-	-
614	R4C-201	-	R4B-201		オムロン	C1S-605G	C1S-601R	-	-	-
615	R4C-202	-	R4B-201		オムロン	C1S-607G	C1S-603R	-	-	-
616	R4C-203	-	R4B-203		オムロン	C1S-605R	C1S-605G	-	-	-
617	R4C-204	-	R4B-203		オムロン	C1S-607R	C1S-607G	-	-	-
618	R4C-205	-	R4B-202		IDEC	C1S-655G	C1S-658R	-	-	-
619	R4C-206	-	R4B-202		IDEC	C1S-656G	C1S-657R	-	-	-
620	R4C-207	-	R4B-204		IDEC	C1S-655R	C1S-655G	-	-	-
621	R4C-208	-	R4B-204		IDEC	C1S-656R	C1S-656G	-	-	-
622	R4C-209	-	R4B-202		富士	C1S-761G	C1S-757R	-	-	-
623	R4C-210	-	R4B-202		富士	C1S-763G	C1S-758R	-	-	-
624	R4C-211	-	R4B-204		富士	C1S-761R	C1S-761G	-	-	-
625	R4C-212	-	R4B-204		富士	C1S-763R	C1S-763G	-	-	-
626	R4C-301	-	R4B-301		オムロン	C1S-605G	C1S-605R	C1S-601R	-	-
627	R4C-302	-	R4B-301		オムロン	C1S-607G	C1S-607R	C1S-603R	-	-
628	R4C-303	-	R4B-303		オムロン	C1S-605Y	C1S-605R	C1S-605G	-	-
629	R4C-304	-	R4B-303		オムロン	C1S-607Y	C1S-607R	C1S-607G	-	-
630	R4C-305	-	R4B-302		IDEC	C1S-655G	C1S-655R	C1S-658R	-	-
631	R4C-306	-	R4B-302		IDEC	C1S-656G	C1S-656R	C1S-657R	-	-
632	R4C-307	-	R4B-304		IDEC	C1S-655Y	C1S-655R	C1S-655G	-	-
633	R4C-308	-	R4B-304		IDEC	C1S-656Y	C1S-656R	C1S-656G	-	-
634	R4C-309	-	R4B-302		富士	C1S-761G	C1S-761R	C1S-757R	-	-
635	R4C-310	-	R4B-302		富士	C1S-763G	C1S-763R	C1S-758R	-	-
636	R4C-311	-	R4B-304		富士	C1S-761Y	C1S-761R	C1S-761G	-	-
637	R4C-312	-	R4B-304		富士	C1S-763Y	C1S-763R	C1S-763G	-	-
638	R6C-101	-	R6B-101		IDEC	C1S-722R	-	-	-	-
639	R6C-102	-	R6B-101		IDEC	C1S-723R	-	-	-	-
640	R6C-103	-	R6B-101		IDEC	C1S-725G	-	-	-	-

No.	オールインワン 機器配線付	配線なし	ボックスのみ	備考	スイッチ メーカー	スイッチ1	スイッチ2	スイッチ3	スイッチ4	スイッチ5
641	R6C-104	-	R6B-101		IDEC	C1S-726G	-	-	-	-
642	R6C-201	-	R6B-201		IDEC	C1S-725G	C1S-722R	-	-	-
643	R6C-202	-	R6B-201		IDEC	C1S-726G	C1S-723R	-	-	-
644	R6C-203	-	R6B-201		IDEC	C1S-725R	C1S-725G	-	-	-
645	R6C-204	-	R6B-201		IDEC	C1S-726R	C1S-726G	-	-	-
646	R6C-301	-	R6B-301		IDEC	C1S-725R	C1S-725G	C1S-722R	-	-
647	R6C-302	-	R6B-301		IDEC	C1S-726R	C1S-726G	C1S-723R	-	-
648	R6C-303	-	R6B-301		IDEC	C1S-725Y	C1S-725R	C1S-725G	-	-
649	R6C-304	-	R6B-301		IDEC	C1S-726Y	C1S-726R	C1S-726G	-	-