






SUC-1098



1	C1S-402G	Illuminated Push button switch UB-15H1NBKG4M-FNS
2	C1S-402R	Illuminated Push button switch UB-15H1NBKG4R-GNS
3	C1S-402Y	Illuminated Push button switch UB-15H1NBKG4Y-HNS
4	C1S-401R	Emergency stop switch FF01-26BBRAYG3





<Associated drawings>
WCW001112-**

2:3
SCALE

Item NO.	SUC-1098
----------	----------



・Terminal Layout.
[端子配置図]



1:UB-15H1NBKG4M-FNS<C1S-402G>
2:UB-15H1NBKG4R-GNS<C1S-402R>
3:UB-15H1NBKG4Y-HNS<C1S-402Y>

4:FF01-26BBRAYG3<C1S-401R>

No.	Switch Model No.	Item No.
1	UB-15H1NBKG4M-FNS	C1S-402G
2	UB-15H1NBKG4R-GNS	C1S-402R
3	UB-15H1NBKG4Y-HNS	C1S-402Y
4	FF01-26BBRAYG3	C1S-401R
5	RD75SJ 1.1KΩ1W	C1P-P027



ケーブル処理詳細